

SKYLIGHT SPECIALISTS

A division of ADS Building Services Ltd
P.O. Box 30 856
Lower Hutt 5010
Phone 04 938 0721
www.skylightspecialists.co.nz
info@nzskylight.nz



NZ made for NZ conditions

Fixed Skylight Installation

Please read below before proceeding with installation.

Fixed non-venting and venting skylight installation

1. Install in seal tape around the top outer edges of flashed timber upstand.
2. Place skylight onto the flashed roof upstand, with drainage channel at bottom (lowest point)
3. Install screws into all the pre-drilled holes into the skylight base frame